wifi:正面



- (1) Scan the QR code or visit the URL from your Andriod or IOS device to download the 'AutoMate' app and
- http://www.topdon.com/topdonwebsite/support-app/3



- (2) IOS: Search for 'AutoMate' on appstore and download and install.
- · Andriod: Download 'AutoMate' at Google application
- (3) You can purchase and use other Apps which support ELM327's functions.

Register & Login



email address & Password you registered Plug EIM327 (Wi-Fi) into the diagnosti

· Open the AutoMate app and Register. Follow the

If you have already registered your account, login with the

on-screen instructions to complete the registeration.

Find the vehicle OBD interface location, OBD interface for the 16-pin interface, for the trapezoidal shape.



Note: Diagnostic link connectors locate in different place on different vehicles, the following figure is OBD interface may



- A: GM, Volkswagen, Ford, Toyota, HYUNDAI, Citroen, BMW and other brands most models.
- B: Honda, Volkswagen touran, Imported Lexus and other
- C: Citroen, Peugeot and other small models.
- D : Citroen and other small models.

蓝牙:正面



AutoMate **Quick Start Guide**

For Bluetooth



1.DownLoad & Install AutoMate app

- (1) Scan the OR code or visit the URL from your Andriod or IOS device to download the 'AutoMate' app and insta**ll** it:
- http://www.topdon.com/topdonwebsite/support-app/3



- (2) IOS: Search for 'AutoMate' on appstore and download and install. · Andriod: Download 'AutoMate' at Google application
- (3) You can purchase and use other Apps which support
- ELM327's functions.

2.Register & Login



D: Citroen and other small models.

connection is successful.

other models

C: Citroen, Peugeot and other small models.

Turn on the device's Bluetooth beforehand for connection.

Click the Connection Type button to select the Bluetooth

Click the Connect button and wait a few seconds until the

A. GM. Volkswagen, Ford, Toyota, HYUNDAI Citroen, BMW and other brands most models.

B: Honda, Volkswagen touran, Imported Lexus and

Open the AutoMate app and Register. Follow the

If you have already registered your account, login with the

Find the vehicle OBD interface location, OBD interface for the 16-pin interface, for the trapezoidal shape.

*0000000

Note: Diagnostic link connectors locate in different place on

different vehicles, the following figure is OBD interface may

on-screen instructions to complete the registeration.

email address & Password you registered

Plug EIM327 (Bluetooth) into the

diagnostic link connector (DLC)

wifi:反面



a ⊕ (i) TPGuest_7C6F

Tap Setting > Connection Management to enter the Connection Management screen



- Click the Connection Type button to select the Wi-Fi
- Click the Connect button and wait a few seconds until the connection is successful.

6. Your 'AutoMate' is now ready to work



蓝牙:反面



TOPDON TECH CO.,LTD website: www.topdon.com Service Hotline: 0755-23576169

Turn Ignition on, press the ELM327 'ON/OFF' button to start communication



ELM327 (Bluetooth) Connection

Tap Setting > Connection Management to enter the



3.Your 'AutoMate' is now ready to work



规格: 55mm X 90mm 128g铜版纸 风琴折页 覆亚膜

TOPDON TECH CO..LTD

website: www.topdon.com Service Hotline: 0755-23576169

